



# **Software User's Manual**

## **Version 2.8**

# Content

<b>Web Management .....</b>	<b>4</b>
<b>Connecting to the Web Console Interface.....</b>	<b>4</b>
<b>Status .....</b>	<b>5</b>
<b>Basic Settings.....</b>	<b>6</b>
Basic Settings > System.....	6
Basic Settings > Change Password .....	7
Basic Settings > IP Setting .....	8
Basic Settings > IPv6 Neighbor Cache .....	9
Basic Settings > IPv6 Setting .....	10
Basic Settings > System Time .....	11
<b>Port Management .....</b>	<b>12</b>
Port Management > Port Status.....	12
13Port Configuration .....	13
<b>PoE .....</b>	<b>15</b>
PoE > PoE Configuration .....	15
PoE > Ping Alarm .....	16
PoE > PoE Schedule.....	17
<b>ERPS.....</b>	<b>18</b>
ERPS > ERPS STATUS .....	18
ERPS > ERPS Configuration .....	20
<b>Spanning Tree .....</b>	<b>22</b>
Spanning Tree > RSTP Status .....	22
Spanning Tree > RSTP Configuration .....	24
Spanning Tree > MSTI Status .....	26
Spanning Tree > MSTI Configuration .....	27
Spanning Tree > MSTI Port Configuration .....	28
<b>IGMP Snooping.....</b>	<b>29</b>
IGMP Snooping > IGMP Snooping Stream Table.....	29
IGMP Snooping > IGMP Snooping Configuration .....	30
<b>VLAN.....</b>	<b>31</b>
VLAN > QinQ VLAN .....	31
32802.1Q VLAN.....	32
<b>QoS.....</b>	<b>34</b>
QoS > QoS Classification.....	34
QoS > CoS Mapping .....	36
QoS > DSCP Mapping .....	37
<b>Port Trunk.....</b>	<b>38</b>
Port Trunk > Trunk Status.....	38
Port Trunk > Trunk Configuration.....	39
<b>Port Mirroring .....</b>	<b>40</b>
Port Mirroring > Port Mirroring.....	40
<b>Security .....</b>	<b>42</b>
Security > Security .....	42
<b>LLDP.....</b>	<b>43</b>
LLDP > LLDP Neighbor.....	43
LLDP > LLDP Configuration .....	44

<b>SNMP</b> .....	<b>45</b>
SNMP > SNMP Agent .....	45
SNMP > Trap Setting .....	47
<b>Storm Protection</b> .....	<b>48</b>
Storm Protection > Storm Protection .....	48
<b>Rate Limit</b> .....	<b>49</b>
Rate Limit > Rate Limit .....	49
<b>DHCP Server/Relay</b> .....	<b>50</b>
DHCP Server/Relay > DHCP Server .....	50
DHCP Server/Relay > DHCP Server Binding .....	52
DHCP Server/Relay > DHCP Relay .....	53
<b>802.1X</b> .....	<b>55</b>
802.1X > 802.1X .....	55
802.1X > Local Database .....	57
802.1X > RADIUS Server .....	58
<b>UPnP</b> .....	<b>59</b>
UPnP > UPnP .....	59
<b>Modbus</b> .....	<b>60</b>
Modbus > Modbus .....	60
<b>System Warning</b> .....	<b>65</b>
System Warning > Syslog Setting .....	65
System Warning > System Event Log .....	66
System Warning > SMTP Setting .....	67
System Warning > Event Selection .....	69
System Warning > Fault Alarm .....	70
<b>MAC Table</b> .....	<b>71</b>
MAC Table > MAC Address Table .....	71
MAC Table > MAC Table Configuration .....	72
<b>Maintenance</b> .....	<b>73</b>
Maintenance > Upgrade .....	73
Maintenance > Reboot .....	73
Maintenance > Default .....	73
<b>Configuration</b> .....	<b>74</b>
Configuration > Save .....	74
Configuration > Backup & Restore .....	74
<b>Log out</b> .....	<b>75</b>
<b>Command Line Management</b> .....	<b>76</b>
Configuration by serial console .....	76
Configuration by Telnet console .....	76
Commander Groups .....	77
<b>Save and Load Configuration File to/from USB</b> .....	<b>89</b>
<b>Upgrade via TFTP</b> .....	<b>90</b>

Software Manual  
Version 1.1 (March 2018)


This manual applies to firmware v2.8 in the following products: LMX-0800(-T), LMX-0802-M(-T), LMX-0802-ST-M(-T), LMX-0802-S3(-T), LMX-0802-ST-S3(-T), LMX-0800G(-T), LMX-0804G-SFP(-T), LMP-0800G(-T), LMP-0800G-24(-T), LMP-0804G-SFP(-T), LMP-1002C-SFP(-T), LMP-1002C-SFP-24(-T), LMX-1002C-SFP(-T), LMX-1002G-SFP(-T), LMX-1202G-SFP(-T), LMX-1204G-SFP(-T), LMP-1002G-SFP(-T), LMP-1002G-SFP-24(-T), LMP-1202G-SFP(-T), LMP-1204G-SFP(-T)

# Web Management

This section describes the Web console interface for Antaira's Industrial Management Switches. This is a **user-friendly** design with advanced management features that allow you to manage switches through any Internet browser.

## Connecting to the Web Console Interface

1. Initiate a connection from a browser to the default IP address: `http://192.168.1.254`  
The Login page appears.
2. The administrator username is `admin` and password is `admin` by default. Enter the username and password and then click the Login button.



**Authorization Required**

Please enter your username and password.

Username	<input type="text" value="admin"/>
Password	<input type="password" value="••••"/>

**NOTE:** Make sure that the PC and switches are on the same logical subnetwork.

# Status

When logged into the Web Console Interface, the status page will be displayed as shown below.

## Status

### IP

MAC:	7C:CB:0D:0C:D1:E6
Mode:	Dynamic
IP Address:	192.168.1.123
Mask:	255.255.255.0
Gateway:	192.168.1.1
DNS Server:	168.95.1.1

### PORT

No.	Link	Speed	Duplex	Rx Byte	Tx Byte	PoE
1	Down	10	half	0	0	No_PD
2	Down	10	half	0	0	No_PD
3	Down	10	half	0	0	No_PD
4	Down	10	half	3826367	178009267	No_PD
5	Down	10	half	0	0	No_PD
6	Down	10	half	6050	133965795	No_PD
7	Down	10	half	0	0	No_PD
8	Up	1000	full	707220	92535677	No_PD
9	Up	100	full	2078707992	858906007	None
10	Up	1000	full	1766730303	2078562566	None
11	Down	10	half	0	0	None
12	Down	10	half	0	0	None

### MAIN

Uptime Date:	7 days, 6:17
Name:	Switch
Location:	
Contact:	

### VERSION

Firmware Version:	2.6
Loader Version:	3.14.18

# Basic Settings

The Basic Settings contain the most common settings for maintenance and control.

## Basic Settings > System

### System Setting

**SWITCH SETTING**

**System Name:**  ?

**System Description:** 12 port Industrial PoE Managed Ethernet Switch

**System Location:**  ?

**System Contact:**  ?

### System Name

Setting	Description	Factory Default
Max. 32 characters	The name for identifying different devices.	Switch

### System Description

Setting	Description	Factory Default
Fixed	Describe this device.	According to the device

### System Location

Setting	Description	Factory Default
Max. 32 characters	The physical location of this device (e.g., telephone closet, 3rd floor).	None

### System Contact

Setting	Description	Factory Default
Max. 32 characters	Maintenance contact information.	None

## Basic Settings > Change Password

The system provides three-level configuration access. The Admin account has read/write access to all configuration parameters. The Manager account can modify the configuration, but cannot reset to default or update the firmware. The User account can view the configuration but cannot make changes.

### Change Password

---

**ACCOUNT MANAGEMENT**

**Admin Password:**  ?

**Confirmation:**  ?

**Manager Password:**  ?

**Confirmation:**  ?

**User Password:**  ?

**Confirmation:**  ?

### Account

User Account Type	Description
Admin	The administrator has full privileges.
Manager	The manager can modify configurations, but cannot reset to default or update the firmware.
User	The user can view status and configurations, but cannot change the configurations in any way.

### Password

Setting	Description	Factory Default
Password (Max. 20 alphanumeric characters)	Enter a new password.	admin manager user
Confirmation (Max. 20 alphanumeric characters)	Type the new password again to confirm.	admin manager user

## Basic Settings > IP Setting

This page is used to set the device's IP address; you can use DHCP to allocate IP addresses or use static IP addresses.

### IP Setting

---

**IPv4 CONFIGURATION**

**DHCP Client:**

**IP Address:**

**Subnet Mask:**

**Gateway:**

**DNS:**

### DHCP Client

Checkbox	Description	Factory Default
Unchecked	Configure IP address, Subnet mask, Gateway and DNS of this device manually.	Unchecked
Checked	The IP address, Subnet mask, Gateway, and DNS will be assigned to this device automatically by the DHCP server.	

### IP Address

Setting	Description	Factory Default
IP address of this device	Manually configure an IP address to this device.	192.168.1.254

### Subnet Mask

Setting	Description	Factory Default
Subnet mask of this device	Manually configure the Subnet mask to the IP address. (e.g., 255.255.0.0 for a Class B network, or 255.255.255.0 for a Class C network).	255.255.255.0

### Gateway

Setting	Description	Factory Default
IP address of the router	Manually configure the IP address of the gateway router.	0.0.0.0

### DNS

Setting	Description	Factory Default
IP address of the DNS server	Manually configure the IP address of the DNS server.	None



## Basic Settings > IPv6 Neighbor Cache

The following information provides the current IPv6 neighbors and their states.

### IPv6 Neighbor Cache

---

IPv6 NEIGHBOR CACHE

IPv6 Address                      Link Layer(MAC) Address    State

-----

### Account

Permission	Description
IPv6 Address	The IPv6 address of nodes attached to the same link.
Link Layer(MAC) Address	The address at the link layer.
State	Indicates if the neighbor is functioning properly.

## Basic Settings > IPv6 Setting

This page is used to enable/ disable the IPv6 support.

### IPv6 Address

---

**IPv6 ENABLE**

IPv6 Enable:

**IPv6 CONFIGURATION**

IPv6 Address	IPv6 Length Prefix	
		<input type="button" value="Add"/>
fe80::7ecb:dff:fe0c:d1e6	64	<input type="button" value="Delete"/>

### IPv6 Enable

Checkbox	Description	Factory Default
Checked	Enables IPv6 support.	Checked
Unchecked	Disables IPv6 support.	

### IPv6 Configuration

Setting	Description	Factory Default
IPv6 Address	Manually configure an IPv6 address on this device. You can add IPv6 addresses by clicking the <b>Add</b> button and use the <b>Delete</b> button to remove them.	Dependent on MAC address
IPv6 length Prefix	Configure the bit-length of the prefix.	64

## Basic Settings > System Time

This page allows you to configure the system time and Network Time Protocol (NTP).

### System Time

---

**NTP**

**Local Time:** Thu Aug 3 09:54:09 UTC 2017

**Current Time:**  :  :  ?

**Current Date:**  /  /  ?

**Select Your Time Zone:**  ▼

**Enable NTP Client:**

**Time Server:**

### Local Time

Displays the local time of the device.

### Current Time

Setting	Description	Factory Default
User-specified time	Configure the local time in 24-hour HH:MM:SS format.	None

### Current Date

Setting	Description	Factory Default
User-specified time	Configure the local date in DD:MM:YY format.	None

### Select Your Time Zone

Setting	Description	Factory Default
Time zone	Select your time zone which is used to determine the local time offset from GMT (Greenwich Mean Time).	UTC (Coordinated Universal Time)

### Enable NTP Client

Setting	Description	Factory Default
Unchecked	Disables time calibration function.	Unchecked
Checked	Enables time calibration function based on information from an NTP server.	

### Time Server

Setting	Description	Factory Default
Domain name	Assign the NTP server.	2.pool.ntp.org

# Port Management

## Port Management > Port Status

This page shows current port status.

### Port Status

#### PORT

No.	Link	Speed	Duplex	Rx Byte	Tx Byte	PoE
1	Down	10	half	0	0	No_PD
2	Down	10	half	0	0	No_PD
3	Down	10	half	0	0	No_PD
4	Down	10	half	3826367	178009267	No_PD
5	Down	10	half	0	0	No_PD
6	Down	10	half	6050	133965795	No_PD
7	Down	10	half	0	0	No_PD
8	Up	1000	full	1142383	113523325	No_PD
9	Down	10	half	2106653818	940382252	None
10	Up	1000	full	1853882837	2107960820	None
11	Down	10	half	0	0	None
12	Down	10	half	0	0	None

#### Port Status

Item	Description
No.	Port Number
Link	Shows if the port is connected. Up is for Link-up (connected) status, and Down is for Link-down (non-connected) status.
Speed	Displays 10 Mbps, 100 Mbps, or 1000 Mbps speed of the connected device.
Duplex	Displays full or half duplex mode of the connected device.
Rx Byte	Number of bytes received (downloaded) by the port.
Tx Byte	Number of bytes transmitted (uploaded) by the port.
PoE	Indicates the PoE status of the port.

## Port Configuration

This page allows you to configure the ports name, speed, and function.

### Port Configuration

---

**PORT**

No.	Link	Port Name	Status	Speed/Duplex	Flow Control
1	down		Enable ▼	Auto ▼	<input type="checkbox"/>
2	down		Enable ▼	Auto ▼	<input type="checkbox"/>
3	down		Enable ▼	Auto ▼	<input type="checkbox"/>
4	down		Enable ▼	Auto ▼	<input type="checkbox"/>
5	down		Enable ▼	Auto ▼	<input type="checkbox"/>
6	down		Enable ▼	Auto ▼	<input type="checkbox"/>
7	down		Enable ▼	Auto ▼	<input type="checkbox"/>
8	up		Enable ▼	Auto ▼	<input type="checkbox"/>
9	down		Enable ▼	Auto ▼	<input type="checkbox"/>
10	up		Enable ▼	Auto ▼	<input type="checkbox"/>
11	down				
12	down				

### Port

Item	Description
No.	Port number
Link	Shows if the port is connected or not. Up is for Link-up (connected) status, and Down is for Link-down (non-connected) status.

### Port Name

Setting	Description	Factory Default
Max. 32 alphanumeric characters	Used to identify the port.	None

### Status

Setting	Description	Factory Default
Enable	Allows data transfer via the port.	Enable
Disable	Turns off the access through the port.	

### Speed/Duplex

Setting	Description	Factory Default
Auto	Allows the port to negotiate with the connected device using the IEEE 802.3u protocol. The port and the connected device will determine the optimum speed for the connection.	Auto
100FDX	Manually select line speed of 100 Mbps full duplex.	
100HDX	Manually select line speed of 100 Mbps half duplex.	
10FDX	Manually select line speed of 10 Mbps full duplex.	
10HDX	Manually select line speed of 10 Mbps half duplex.	

**Flow Control**

Checkbox	Description	Factory Default
Unchecked	Disable the Flow Control function.	Unchecked
Checked	Enable Flow Control when Speed/Duplex is set to Auto.	

# PoE

Power over Ethernet (PoE) is a technology that uses network cables to carry electrical power and data to Powered Devices (PD).

## PoE > PoE Configuration

This page allows you to control PoE for each port and monitor PD status.

### PoE Configuration

**PoE PORT**

No.	Status	Mode	Consumption
1	No PD Detected	Enable ▼	0.00W
2	No PD Detected	Enable ▼	0.00W
3	No PD Detected	Enable ▼	0.00W
4	No PD Detected	Enable ▼	0.00W
5	No PD Detected	Enable ▼	0.00W
6	No PD Detected	Enable ▼	0.00W
7	No PD Detected	Enable ▼	0.00W
8	No PD Detected	Enable ▼	0.00W

### PoE Port

Item	Description
No.	Number of the PoE port.
Status	Indicates the PoE port status.
Mode	Enable/ Disable PoE on the port. The default configuration is Enable.
Consumption	Shows the PoE consumption on the port.

## PoE > Ping Alarm

The PoE ping alarm function uses the ping command to recycle any PoE port. Insert any Powered Device's IP address and set the interval time between pings for each port. After 3 pings are not returned, PoE power will recycle for that individual port.

### Power over Ethernet

---

**PING ALARM**

PD	IP Address	Cycle Time(s)
1	<input type="text"/>	<input type="text"/>
2	<input type="text"/>	<input type="text"/>
3	<input type="text"/>	<input type="text"/>
4	<input type="text"/>	<input type="text"/>
5	<input type="text"/>	<input type="text"/>
6	<input type="text"/>	<input type="text"/>
7	<input type="text"/>	<input type="text"/>
8	<input type="text"/>	<input type="text"/>

### Ping Alarm

Item	Description
PD	The port number the Powered Device which is connected on the PoE/PSE port.

### IP Address

Setting	Description	Factory Default
IP Address	Insert IP address of Powered Device.	None

### Cycle Times

Setting	Description	Factory Default
0~65535	Set the interval time (second) between pings for individual port.	None



## PoE > PoE Schedule

This page allows you to create a schedule for enabling / disabling PoE.

### Power over Ethernet

---

**PoE Schedule: Port1**

Port1 Port2 Port3 Port4 Port5 Port6 Port7 Port8

**Sunday Enable:**

**Start Time:** Disable ▼

**End Time:** Disable ▼

**Monday Enable:**

**Start Time:** Disable ▼

**End Time:** Disable ▼

**Tuesday Enable:**

**Start Time:** Disable ▼

**End Time:** Disable ▼

**Wednesday Enable:**

**Start Time:** Disable ▼

**End Time:** Disable ▼

**Thursday Enable:**

**Start Time:** Disable ▼

**End Time:** Disable ▼

**Friday Enable:**

**Start Time:** Disable ▼

**End Time:** Disable ▼

**Saturday Enable:**

**Start Time:** Disable ▼

**End Time:** Disable ▼

Apply

### PoE Schedule Tabs

Buttons	Description	Factory Default
Port1~8 buttons	Switch the PoE schedule settings menu from port1 to port8.	Port1

### Sunday / Monday / Tuesday / Wednesday / Thursday / Friday / Saturday Enable

Checkbox	Description	Factory Default
Unchecked	Disables the schedule for day selected.	Unchecked
Checked	Enables the schedule for day selected.	

### Start/ End Time

Setting	Description	Factory Default
Disable	PoE schedule is disabled.	Disable
0~23	Select the start and end time for the Powered Device.	

# ERPS

Ethernet Ring Protection Switching (ERPS), defined in ITU-T G8032, implements a protection switching mechanism for Ethernet traffic in a ring topology. By performing the ERPS function, potential loops in a network can be avoided by blocking traffic to flow to the ring protection link (RPL) to protect the entire Ethernet ring. There can be only one RPL owner and neighbor for each ring. Owner and neighbor ports must be connected for ring to function properly.

## ERPS > ERPS STATUS

### ERPS STATUS

#### ERPS Status

<b>Protocol:</b>	Enable
<b>Ring ID:</b>	1
<b>Channel:</b>	1
<b>Ring State:</b>	Abnormal
<b>Revertive:</b>	Enable
<b>R-APS MEL:</b>	7
<b>Hold-off Timer Setting:</b>	0 ms
<b>Guard Timer Setting:</b>	500 ms
<b>WTR Timer Setting:</b>	5 minutes
<b>NODE State:</b>	PROTECTION
<b>Port0 Information</b>	
<b>Port:</b>	1
<b>Role:</b>	None
<b>Status:</b>	Forwarding
<b>Receive Node ID:</b>	00:00:00:00:00:00
<b>Receive BPR:</b>	0
<b>Port1 Information</b>	
<b>Port:</b>	2
<b>Role:</b>	None
<b>Status:</b>	Blocking
<b>Receive Node ID:</b>	00:00:00:00:00:00
<b>Receive BPR:</b>	0

Item	Description
Protocol	Indicate ERPS protocol is enabled or disabled.

Item	Description
Ring ID	ERPS ring ID, ranges from 1 to 239. Ring ID distinguishes different ring topology.
Channel	ERPS Channel ID, ranges from 1 to 4094. It's a channel to send PDUs of ERPS.
Ring State	Displays ring port status.
Revertive	Indicates if Revertive Mode is enabled or disabled.
R-APS MEL	Displays the R-APS MEL value.
Hold-off Timer Settings	Displays the Hold-off Timer expiration setting.
Guard Timer Setting	Displays the Guard Timer expiration setting.
WTR Timer Setting	Displays the WTR (Wait to Restore) Timer expiration setting.
NODE State	<p>The following are the different states for each node of a specific ring:</p> <p>INIT - Not a participant of a specific ring.</p> <p>IDLE - No failure on the ring; the node is performing normally. For a normal node, traffic is unblocked on both ring ports. For the RPL owner or RPL neighbor, traffic is blocked on the ring port that connects to the RPL and unblocked on the other ring port.</p> <p>PROTECTION - A failure occurred on the ring. For a normal node, traffic is blocked on the ring port that connects to the failing link and unblocked on working ring ports. For the RPL owner, traffic is unblocked on both ring ports if they connect to non-failure links.</p> <p>PENDING - The node is recovering from a failure or its state after a clear command is used to remove the previous manual command. When a protection group is configured, the node enters the pending state. When a node is in pending state, the WTR or WTB timer will be running. All nodes are in pending state until WTR or WTB timer expire.</p> <p>FORCE SWITCH - A force switch is issued. When a force switch is issued on a node in the ring, all nodes in the ring will move into the force switch state.</p> <p>MANUAL SWITCH - A manual switch is issued. When a manual switch is issued on a node in the ring, all nodes in the ring will move into the manual switch state.</p>

### Port(x) Information

Item	Description
Port	Port number that is participating in the ring.
Role	<p>The following are the different states for ERPS role:</p> <p>Owner - In charge of blocking one side of RPL link. It will prevent the packet flow from its blocked port.</p> <p>Neighbor - In charge of blocking one side of RPL link. It will prevent the packet flow from its blocked port.</p> <p>None - Besides Owner and Neighbor node, all other nodes are defined as None node.</p>
Status	Display the port status information.
Receive Node ID	The MAC address of message source node.
Receive BPR	Display the Receive BPR value.

## ERPS > ERPS Configuration

This page allows you to enable / disable ERPS and configure the ERPS settings.

**NOTE:** Before configuring ERPS, rapid spanning tree protocol (RSTP) and multiple spanning tree protocol is required to be disabled. Only one protocol can be running within a switch at once.

### ERPS Configuration

**ERPS CONFIGURATION**

Protocol:	<input type="text" value="Enable"/>	
Ring Port 0:	<input type="text" value="1"/>	
Role:	<input type="text" value="None"/>	
Ring Port 1:	<input type="text" value="2"/>	
Role:	<input type="text" value="None"/>	
Ring ID:	<input type="text" value="1"/>	
APS Channel:	<input type="text" value="1"/>	
Revertive:	<input type="text" value="Enable"/>	

#### Protocol

Setting	Description	Factory Default
Disable	Disables ERPS protocol.	Disable
Enable	Enables ERPS protocol.	

#### Ring Port 0

Setting	Description	Factory Default
Port number	Switch port number that is participating in the ERPS ring.	1

#### Ring Port 1

Setting	Description	Factory Default
Port number	Switch port number that is participating in the ERPS ring.	2

**NOTE:** Ring Port 1 and Ring Port 0 must use different ports on switch.

#### Role

Setting	Description	Factory Default
None	Besides Owner and Neighbor node, all other of nodes are defined as None nodes.	None
Owner	In charge of blocking one side of the RPL link. This prevents packet flow from the blocked port.	
Neighbor	In charge of blocking one side of the RPL link. This prevents packet flow from the blocked port.	

**Ring ID**

Setting	Description	Factory Default
1~239	ERPS ring ID, ranges from 1 to 239. Ring ID distinguishes different rings.	0

**APS Channel**

Setting	Description	Factory Default
1~4094	ERPS Channel ID, ranges from 1 to 4094. This is the channel set to send PDU (protocol data units) for the ERPS ring.	0

**Revertive**

Setting	Description	Factory Default
Disable	The failed ring link and the port attached to it will remain blocked even the situation is eliminated.	Disable
Enable	The RPL link will be blocked for the time interval set by WTR timer after recovery from link failure situation. Otherwise, it will remain unchanged from the blocking state. That is, the failed link port will block permanently until the next event happens.	

# Spanning Tree

Rapid Spanning Tree Protocol (RSTP) is defined by IEEE 802.1w. RSTP is an enhanced version of STP (Spanning Tree Protocol). It shares most of its basic operation characteristics, and creates a cascading effect away from the root bridge where each designated bridge proposes to its neighbors to determine if it should disable traffic to prevent a loop.

## Spanning Tree > RSTP Status

### RSTP/CIST Status

#### ROOT STATUS

Bridge ID:	7C:CB:0D:0C:D1:E6
Root Priority:	32768
Root Port:	Port10
Root Path Cost:	0
Hello Time:	2
Forward Delay:	15
Max Age:	20

#### RSTP/CIST PORT STATUS

No.	Role	Path State	Port Cost	Port Priority	Oper P2P	Oper Edge
Port1	Disabled	discarding	200000000	128	Shared	Non-Edge
Port2	Disabled	discarding	200000000	128	Shared	Non-Edge
Port3	Disabled	discarding	200000000	128	Shared	Non-Edge
Port4	Disabled	discarding	20000	128	Shared	Non-Edge
Port5	Disabled	discarding	200000000	128	Shared	Non-Edge
Port6	Disabled	discarding	20000	128	Shared	Non-Edge
Port7	Disabled	discarding	200000000	128	Shared	Non-Edge
Port8	Designated	forwarding	20000	128	Shared	Edge
Port9	Designated	forwarding	200000	128	Shared	Edge
Port10	Root	forwarding	20000	128	Shared	Non-Edge
Port11	Disabled	discarding	200000000	128	Shared	Non-Edge
Port12	Disabled	discarding	200000000	128	Shared	Non-Edge

#### Root Status

Item	Description
Bridge ID	The Bridge MAC address.
Root Priority	The lowest priority will become the Root Bridge.
Root Port	The port receiving traffic from the Root Bridge.
Root Path Cost	The STP cost between this switch and the current root.
Hello Time	Time interval between each Bridge Protocol Data Unit (BPDU) that is sent on a port.
Forward Delay	Delay time in seconds unit network converts to forwarding state.
Max Age	Maximum length of time that passes before a bridge port saves its configuration.

#### RSTP/CIST Port Status

Item	Description
No.	Port number of the switch.

Item	Description
Role	<p>The role of the port:</p> <p>[Root] The port closest to the root bridge, in terms of least path cost (based on BPDU), is determined to be the root port.</p> <p>[Designated] The designated port is the port that can send the best BPDU on the segment to which it is connected.</p> <p>[Alternate] The alternate port roles correspond to the blocking state of RSTP.</p> <p>[Disabled] There is no link on the port.</p>
Path State	The path to the Root Bridge. Forwarding indicates that traffic is moving across the port. Discarding indicates that the port is blocking traffic to prevent a loop.
Port Cost	The Root Path Cost of the port.
Port Priority	The Root Priority of the port.
Oper P2P	The P2P status of the port.
Oper Edge	The Edge status of the port.

## Spanning Tree > RSTP Configuration

This page allows you to enable / disable the RSTP function and configure the settings for each port.

### RSTP/CIST Configuration

#### RSTP/CIST

Mode:	RSTP ▼
Root Priority:	32768 ▼
Root Hello Time:	2
Root Forward Delay:	15
Root Maximum Age:	20

#### RSTP/CIST PORT

No.	Path Cost	Priority	Admin P2P	Edge	Admin Non STP
1	0	128 ▼	False ▼	Auto ▼	False ▼
2	0	128 ▼	False ▼	Auto ▼	False ▼
3	0	128 ▼	False ▼	Auto ▼	False ▼
4	0	128 ▼	False ▼	Auto ▼	False ▼
5	0	128 ▼	False ▼	Auto ▼	False ▼
6	0	128 ▼	False ▼	Auto ▼	False ▼
7	0	128 ▼	False ▼	Auto ▼	False ▼
8	0	128 ▼	False ▼	Auto ▼	False ▼
9	0	128 ▼	False ▼	Auto ▼	False ▼
10	0	128 ▼	False ▼	Auto ▼	False ▼
11	0	128 ▼	False ▼	Auto ▼	False ▼
12	0	128 ▼	False ▼	Auto ▼	False ▼

Apply

#### Mode

Setting	Description	Factory Default
Disable	Disables RSTP function	Disable
RSTP	Enables RSTP function	
MSTP	Enables MSTP function	

#### Root Priority

Setting	Description	Factory Default
0~61440	The value used to identify the Root Bridge. The bridge with the lowest value has the highest priority and is selected as the root. If there is any change of the value, the switch must be power cycled. The value must be a multiple of 4096 according to the standard rule of the protocol.	32768

#### Root Hello Time

Setting	Description	Factory Default
1~10	Controls the time interval to send out the BPDU packet for checking RSTP's current status.	2



**Root Forward Delay**

Setting	Description	Factory Default
4~30	Enter a value between 4 and 30 for the number of seconds a port is to wait before changing from its learning and listening states to the forwarding state.	15

**Root Maximum Age**

Setting	Description	Factory Default
6~40	Enter a value between 6 and 40 for the number of seconds a bridge waits without receiving STP configuration messages before attempting a reconfiguration.	20

**Path Cost**

Setting	Description	Factory Default
0~200000000	Enter a value from 1 through 200000000 to define the path cost for the other switch from this transmitting switch at the specified port. When path cost is set to 0, the switches will be setup as automatic data transmitting.	0

**Priority**

Setting	Description	Factory Default
0, 16, 32, 48, 64, 80, 96, 112, 128, 144, 160, 176, 192, 208, 224, 240	Enter a number 0 through 240 to decide which port should be blocked by priority. The value of priority must be the multiple of 16.	128

**Admin P2P**

Some of the rapid state transactions that are possible within RSTP are dependent upon whether the port concerned can only be connected to exactly one other switch (i.e. it is served by a point-to-point LAN segment), or it can be connected to two or more switches (i.e. it is served by a shared medium LAN segment). This function allows the P2P status of the link to be manipulated administratively.

Setting	Description	Factory Default
False	Disables P2P function.	False
True	Enables P2P function.	

**Edge**

Setting	Description	Factory Default
Auto	If any incoming RST BPDU is received from a previously configured Edge port, 802.1W automatically makes the port as a non-edge port.	Auto
Admin True	Enables Admin Edge Port.	
Admin False	Disables Admin Edge Port.	

**Admin Non STP**

Setting	Description	Factory Default
False	Includes the STP mathematic calculation.	False
True	Not includes STP mathematic calculation.	

## Spanning Tree > MSTI Status

This page shows Multiple Spanning Tree Instance (MSTI) status.

### MSTI Status

---

Instance1

Instance2

Instance3

Instance4

Instance5

Instance6

Instance7

Instance8

Instance9

Instance10

Instance11

Instance12

Instance13

Instance14

Instance15

**Instance1**

**Root Address:**

**Root Priority:**

**Root Port:**

**Root Path Cost:**

No.	Role	Path State	Port Cost	Port Priority

### Instance1~15 buttons

These buttons allow you to select Instance Tab #1~#15 to configure each MSTI port **Cost & Priority** value.

### Instance1~15

Item	Description
Root Address	The root address of the MST instance.
Root Priority	The switch priority for the designated instance.
Root Port	The root port for the designated instance.
Root Path Cost	The root cost for the MST instance.

## Spanning Tree &gt; MSTI Configuration

## MSTI Configuration

---

**MSTI CONFIGURATION**

Name:

Revision(0-65535):

**MSTI INSTANCE**

Instance.	Vlan group	Priority
1	<input style="width: 150px;" type="text"/>	32768 ▼
2	<input style="width: 150px;" type="text"/>	32768 ▼
3	<input style="width: 150px;" type="text"/>	32768 ▼
4	<input style="width: 150px;" type="text"/>	32768 ▼
5	<input style="width: 150px;" type="text"/>	32768 ▼
6	<input style="width: 150px;" type="text"/>	32768 ▼
7	<input style="width: 150px;" type="text"/>	32768 ▼
8	<input style="width: 150px;" type="text"/>	32768 ▼
9	<input style="width: 150px;" type="text"/>	32768 ▼
10	<input style="width: 150px;" type="text"/>	32768 ▼
11	<input style="width: 150px;" type="text"/>	32768 ▼
12	<input style="width: 150px;" type="text"/>	32768 ▼
13	<input style="width: 150px;" type="text"/>	32768 ▼
14	<input style="width: 150px;" type="text"/>	32768 ▼
15	<input style="width: 150px;" type="text"/>	32768 ▼

**MSTI Configuration**

Item	Description
Name	The MAC address of the bridge switch.
Revision (0-65535)	Specifies the revision level for MSTP that you are configuring on the switch. The default revision number is 0.

**MSTI Instance**

Item	Description
Instance	Instance number.

**VLAN group**

Setting	Description	Factory Default
VLAN Number	Enter VLAN information of the instance. Max value is 4094.	None

**Priority**

Setting	Description	Factory Default
0~61440	<p>Used to identify the root bridge.</p> <p>The bridge with the lowest value has the highest priority and is selected as the root.</p> <p>The switch is required to reboot when there is a value change.</p> <p>The value must be a multiple of 4096 according to the standard rule of the protocol.</p>	32768

## Spanning Tree > MSTI Port Configuration

This page allows you to configure and view parameters per MST Instance.

### MSTI Port Configuration

---

**MSTI PORT**

Instance1

Instance2

Instance3

Instance4

Instance5

Instance6

Instance7

Instance8

Instance9

Instance10

Instance11

Instance12

Instance13

Instance14

Instance15

**Instance1**

Port No.	Cost	Priority
1	0	128 ▼
2	0	128 ▼
3	0	128 ▼
4	0	128 ▼
5	0	128 ▼
6	0	128 ▼
7	0	128 ▼
8	0	128 ▼
9	0	128 ▼
10	0	128 ▼
11	0	128 ▼
12	0	128 ▼

**Instance**

Item	Description
No.	Port number of the switch.

**Cost**

Setting	Description	Factory Default
0~200000000	Defines the path cost value from 1 through 200000000 to the other bridge from this transmitting bridge at the specified port.	0

**Priority**

Setting	Description	Factory Default
0, 16, 32, 48, 64, 80, 96, 112, 128, 144, 160, 176, 192, 208, 224, 240	Enter a number 0 through 240 to decide which port should be blocked by priority. The value of priority must be the multiple of 16.	128

# IGMP Snooping

The Internet Group Management Protocol (IGMP) is a communications protocol used to manage the membership of Internet Protocol multicast groups. IGMP is used by IP hosts and adjacent multicast routers to establish multicast group memberships.

## IGMP Snooping > IGMP Snooping Stream Table

Multicast filtering is the system by which end stations only receive multicast traffic if they register to join specific multicast groups. With multicast filtering, network devices only forward multicast traffic to the ports that are connected to registered end stations.

### **IGMP Snooping Table**

---

#### **IGMP SNOOPING TABLE**

<b>Group</b>	<b>Port</b>
239.255.255.250	10,

## IGMP Snooping > IGMP Snooping Configuration

This page allows you to enable / disable the IGMP Snooping function and configure the settings.

### IGMP Snooping Configuration

**IGMP SNOOPING**

IGMP Snooping Enable:

**IGMP QUERIER**

Querier Enable:

Query Interval(s):

Query Max Response Time(s):

### IGMP Snooping Enable

Setting	Description	Factory Default
Checked	Enables the IGMP Snooping function.	Checked
Unchecked	Disables the IGMP Snooping function.	

### Query Enable

Setting	Description	Factory Default
Checked	Enables the Querier.	Unchecked
Unchecked	Disables the Querier.	

### Query Interval(s)

Setting	Description	Factory Default
1~3600	The frequency at which the querier sends query messages. These messages are used to build the IGMP snooping tables.	125

### Query Max Response Time(s)

Setting	Description	Factory Default
1~12	The maximum response time advertised.	10

# VLAN

A Virtual LAN (VLAN) is a logical network grouping that limits the broadcast domain which allows users to isolate network traffic. Only the members of a VLAN will receive traffic from the same members on that VLAN. Creating a VLAN on a switch is the equivalent of reconnecting a group of network devices to another Layer 2 switch. However, all the network devices are still physically plugged into the same switch.

## VLAN > QinQ VLAN

This page allows you to configure IEEE 802.1Q-in-Q (Q-in-Q) VLAN.

### QinQ VLAN

---

**QinQ VLAN**

**QinQ Ethertype:**

**QinQ PORT MODE**

Port	Port Mode
1	Customer ▼
2	Customer ▼
3	Customer ▼
4	Customer ▼
5	Customer ▼
6	Customer ▼
7	Customer ▼
8	Customer ▼
9	Customer ▼
10	Customer ▼
11	Customer ▼
12	Customer ▼

### QinQ Ethertype

Setting	Description	Factory Default
0x0001~0xFFFF	It is used to indicate which protocol is encapsulated in the payload of the frame. The same field is also used to indicate the size of some Ethernet frames. Ethertype was first defined by the Ethernet II framing standard, and later adapted for the IEEE 802.3 standard.	0x88a8

### Port

Item	Description
Port No.	Number of the port.

### Port Mode

Setting	Description	Factory Default
Customer	Specifies the port to the general port.	Customer
Dot1q-tunnel	Specifies the port to the client port.	
Provider	Specifies the port to the ISP port.	

## 802.1Q VLAN

This page allows you to configure VLAN (IEEE 802.1Q) protocol.

### 802.1Q VLAN

**MANAGEMENT VLAN SETTING**

Management VLAN ID:

**802.1Q VLAN**

ID	Name	01	02	03	04	05	06	07	08	09	10	11	12	
		U	U	U	U	U	U	U	U	U	U	U	U	Add

**802.1Q VLAN PVID/FILTER**

Port	PVID	Ingress Acceptable Frame Types Filter
1	1	All
2	1	All
3	1	All
4	1	All
5	1	All
6	1	All
7	1	All
8	1	All
9	1	All
10	1	All
11	1	All
12	1	All

### Management VLAN ID

Setting	Description	Factory Default
1~4094	Set the VLAN ID of management VLAN. The management VLAN is the VLAN on which the switch expects to receive management traffic.	1

### 802.1Q VLAN

Item	Description	Factory Default
ID	The ID of the VLAN.VLANs that have the same ID will be treated as if on the same network. Devices with different VLAN IDs will not be able to see each other.	None
Name	The name of this VLAN. VLAN names can be different in each switch.	None

### 802.1Q VLAN PVID/ Filter

Item	Description	Factory Default
Port	Number of the port.	None
PVID	When a frame comes into the port, it will be tagged with the PVID if the frame is without VLAN tag.	1



Item	Description	Factory Default
Ingress Acceptable Frame Types Filter	<p data-bbox="443 197 1217 259">An incoming frame will be dropped or forwarded according to the port filter.</p> <p data-bbox="443 277 895 309">[All] All frames are forwarded.</p> <p data-bbox="443 327 1206 389">[Tagged] Only the frames with 802.1Q tags can be forwarded, untagged frames will be dropped.</p> <p data-bbox="443 407 1139 465">[Untagged] Only the frames without an 802.1Q tag can be forwarded, tagged frames will be dropped.</p>	All

## QoS

QoS provides the ability to assign different priorities to different devices which can be improved through traffic shaping methods. These methods include prioritization of packets and device classification. A priority queue is a data type which identifies an item with the highest priority in a system. The CoS Mapping is used to map each CoS value to a QoS priority queue. The purpose of this is to prioritize types of traffic at congestion points of the network.

Some devices provide QoS based IEEE 802.1p Class of Service (CoS) values and Differentiated Services Code Point (DSCP) values for implementing Quality of Service (QoS) at the Media Access Control level.

### QoS > QoS Classification

This page allows you to configure QoS Classification.

### QoS Classification

---

**QoS CLASSIFICATION**

Queue Scheduling: Weighted ▼

Port	Trust Mode	Default Cos
1	DSCP ▼	0 ▼
2	DSCP ▼	0 ▼
3	DSCP ▼	0 ▼
4	DSCP ▼	0 ▼
5	DSCP ▼	0 ▼
6	DSCP ▼	0 ▼
7	DSCP ▼	0 ▼
8	DSCP ▼	0 ▼
9	DSCP ▼	0 ▼
10	DSCP ▼	0 ▼
11	DSCP ▼	0 ▼
12	DSCP ▼	0 ▼

#### Queue Scheduling

Setting	Description	Factory Default
Weighted	Weighting applies a round robin priority to the queues. The queues are emptied from highest to lowest priority by frame rates of 8, 4, 2, 1.	Weighted
Strict	Gives egress queues with higher priority to be transmitted first before lower priority queues are serviced. An entire queue must be emptied before moving to the next set.	

**Trust Mode**

Setting	Description	Factory Default
DSCP	Only trusted DSCP (Differentiated Services Code Point) values are mapped to a specific QoS class and drop precedence level (DPL). Frames with untrusted DSCP values are treated as non-IP frames.	DSCP
CoS	(Class of Service) is known as 802.1p. It describes that the output priority of a packet is determined by user priority field in 802.1Q VLAN tag. The priority value supports 0 to 7 CoS values mapped to 4 priority levels.	
Queues	Highest, SecHigh, SecLow, and Lowest.	

**Default CoS**

Setting	Description	Factory Default
0~7	Set each port's priority queue from 0 to 7. By default, 0 is the highest, and 7 is the lowest.	0

## QoS > CoS Mapping

This page allows you to configure Class of Service (CoS) Mapping.

### CoS Mapping

---

**CoS MAPPING**

Priority	Queue
0	1 ▼
1	0(Lowest) ▼
2	2 ▼
3	3 ▼
4	4 ▼
5	5 ▼
6	6 ▼
7	7(Highest) ▼

### CoS Mapping

Setting	Description	Factory Default
0(Lowest)~7(Highest)	Maps different CoS values to 0~7 designated egress queues.	0: 1 1: 0(Lowest) 2: 2 3: 3 4: 4 5: 5 6: 6 7: 7(Highest)

**NOTE:** Priority 0 is set as queue 1 so unprioritized packets are given some weight in the network.

## QoS > DSCP Mapping

This page allows you to configure Differentiated Services Code Point (DSCP) Mapping.

### DSCP Mapping

---

**DSCP MAPPING**

Priority Queue	Priority Queue	Priority Queue	Priority Queue
0	0(Lowest) ▼	16	2 ▼
1	0(Lowest) ▼	17	2 ▼
2	0(Lowest) ▼	18	2 ▼
3	0(Lowest) ▼	19	2 ▼
4	0(Lowest) ▼	20	2 ▼
5	0(Lowest) ▼	21	2 ▼
6	0(Lowest) ▼	22	2 ▼
7	0(Lowest) ▼	23	2 ▼
8	1 ▼	24	3 ▼
9	1 ▼	25	3 ▼
10	1 ▼	26	3 ▼
11	1 ▼	27	3 ▼
12	1 ▼	28	3 ▼
13	1 ▼	29	3 ▼
14	1 ▼	30	3 ▼
15	1 ▼	31	3 ▼

### DSCP Mapping

Setting	Description	Factory Default
0(Lowest)~7(Highest)	Maps different DSCP values to 0~7 designated egress queues.	0~7: 0(Lowest) 8~15: 1 16~23: 2 24~31: 3 32~39: 4 40~47: 5 48~55: 6 56~63: 7(Highest)

# Port Trunk

Port Trunk, also called Link Aggregation, is a method of combining multiple network connections in parallel. This is to increase throughput beyond what a single connection could sustain. For example, if the application requires a 5-Gigabit link, and each port supports only 1-Gigabit link, the Port Trunk allows users to link 5, 1-Gigabit ports together to obtain a 5-Gigabit trunk. There are 2 types of Port Trunk. One is LACP (dynamic) and the other is Static.

- LACP mode is more flexible, and it can change modes to either trunk or single port.
- Dynamic Port Trunk also provides a redundancy function in case one of the links fail. If one of the trunk members has failed, it will still work well in LACP mode. Please note, it will show link down if using static mode. Although it is not advised, static mode is still necessary as some devices only support static trunks.

## Port Trunk > Trunk Status

### Trunk Status

---

**AGGREGATION**

Group	Type	Port
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	-	-
8	-	-

### Aggregation

Item	Description
Group	Trunk group number.
Type	Truck type of aggregated group (LACP or static).
Port	The port numbers of aggregated group members.

## Port Trunk > Trunk Configuration

### Trunk Configuration

**AGGREGATION GROUP TYPE**

Group ID	TrunkType
Trunk1	LACP ▼
Trunk2	LACP ▼
Trunk3	LACP ▼
Trunk4	LACP ▼
Trunk5	LACP ▼
Trunk6	LACP ▼
Trunk7	LACP ▼
Trunk8	LACP ▼

**AGGREGATION GROUP MEMBER**

Port No.	Group ID
Port1	None ▼
Port2	None ▼
Port3	None ▼
Port4	None ▼
Port5	None ▼
Port6	None ▼
Port7	None ▼
Port8	None ▼
Port9	None ▼
Port10	None ▼
Port11	None ▼
Port12	None ▼

### Aggregation Group Type

Item	Description
Group ID	Name of aggregated ports.

### DSCP Mapping

Setting	Description	Factory Default
LACP	Dynamic trunking. If a link in a trunk goes down, the traffic will be routed to the remaining links.	LACP
Static	Static trunking. If any link goes down in the trunk, the entire trunk will go down.	

### Aggregation Group Member

Item	Description
Port No.	The port number on the switch being aggregated into a group.

### Group ID

Setting	Description	Factory Default
None	Disables the mapping function.	None
Trunk1~Trunk8	Assigns port to Trunk1~Trunk8.	

# Port Mirroring

Port mirroring is an approach to monitoring network traffic that involves forwarding a copy of each packet from one network switch port to another.

## Port Mirroring > Port Mirroring

This page allows you to enable / disable port mirroring feature. When enabled, a matching copy of frames will be mirrored to the destination port specified in the port mirroring interface.

### Port Mirroring

---

**PORT MIRRORING**

**Port Mirror Mode:**

**Destination port:** None ▼

**Monitor Direction:** None ▼

**Source Port:**

**Port1:**

**Port2:**

**Port3:**

**Port4:**

**Port5:**

**Port6:**

**Port7:**

**Port8:**

**Port9:**

**Port10:**

**Port11:**

**Port12:**

Apply

### Port Mirroring Mode

Setting	Description	Factory Default
Unchecked	Disables Port Mirroring function.	Unchecked
Checked	Enables Port Mirroring function.	

### Destination Port

Setting	Description	Factory Default
None	No destination port.	None
Port number	Select one port to be the destination (mirroring) port for monitoring both RX and TX traffic coming from the source port.	



**Monitor Direction**

Setting	Description	Factory Default
None	Disables monitor function.	None
Tx	Monitors Tx traffic coming (outgoing traffic).	
Rx	Monitors Rx traffic coming (incoming traffic).	
Tx/Rx	Monitors Tx/Rx traffic coming (Bi directional traffic).	

**Source Port: Port1 ~ Port12**

Setting	Description	Factory Default
Unchecked	Disables Port Mirroring function of the port.	Unchecked
Checked	Enables Port Mirroring function of the port to send traffic to the destination port.	

# Security

You can access the command-line interface and web interface on the device over the network. This page allows you to enable / disable the Telnet, SSH, HTTP, and HTTPS access.

## Security > Security

### Security

---

**TELNET CONFIGURATION**

telnet enable:

**SSH CONFIGURATION**

ssh enable:

**HTTP CONFIGURATION**

http enable:

**HTTPS CONFIGURATION**

https enable:

### telnet enable

Setting	Description	Factory Default
Checked	Allows telnet access.	Checked
Unchecked	Denies telnet access.	

### ssh enable

Setting	Description	Factory Default
Checked	Allows ssh access.	Checked
Unchecked	Denies ssh access.	

### http enable

Setting	Description	Factory Default
Checked	Allows http access.	Checked
Unchecked	Denies http access.	

### https enable

Setting	Description	Factory Default
Checked	Allows https access.	Checked
Unchecked	Denies https access.	

## LLDP

LLDP is a neighbor discovery protocol that is used for network devices to advertise information about themselves to other devices on the network. This protocol runs over the data-link layer which allows two systems running different network layer protocols to learn about each other.

### LLDP > LLDP Neighbor

LLDP Neighbor						
LLDP NEIGHBOR						
Local Port	Chassis ID	Remote Port ID	System Name	Port Description	System Capabilities	Management Address

#### LLDP Neighbor

Item	Description
Local Port	The port which connects directly / indirectly to the LLDP device used to transmit/ receive LLDP packets.
Chassis ID	The MAC address of the LLDP neighbor.
Remote Port ID	The number of the port which connects directly / indirectly to this local switch.
System Name	The device name defined on the LLDP neighbor.
Port Description	The description for the port defined on the LLDP neighbor.
System Capabilities	<p>The capabilities of the LLDP neighbor, including:</p> <ol style="list-style-type: none"> <li>1. Bridge: Layer 2 devices, like switches, used in LAN</li> <li>2. Router: Layer 3 devices which used to connect to Internet</li> <li>3. WLAN Access Point: Wireless devices</li> </ol> <p>Capabilities always followed by a (+) or (-). (+) means <b>enabled</b> and (-) means <b>disabled</b>.</p>
Management Address	The IP address of the LLDP neighbor. User can access and configure the system by this management address.

## LLDP > LLDP Configuration

This page allows you to enable / disable the LLDP function and configure the settings.

### LLDP Configuration

**LLDP CONFIGURATION**

LLDP Enable:

LLDP Timer:

### LLDP Enable

Setting	Description	Factory Default
Unchecked	Disables LLDP function.	Unchecked
Checked	Enables LLDP function.	

### LLDP Timer

Setting	Description	Factory Default
5~32768	Sets the transmit interval of LLDP messages (in seconds).	30

# SNMP

Simple Network Management Protocol (SNMP) is the protocol developed to manage nodes (servers, workstations, routers, switches, hubs, etc.) on an IP network. SNMP enables network administrators to manage network performance, find and solve network problems, and plan for network growth. Network management systems become aware of problems by receiving traps or change notices from network devices implementing SNMP.

## SNMP > SNMP Agent

### SNMP Agent

---

**SNMP GENERAL**

SNMP Version:

Read-Only Community:

Read and Write Community:

**SNMP v3**

Admin Auth Level:

Admin Auth Type:

Auth Passphrase:

Admin Data Encrypt Type:

Encrypt Passphrase:

User Auth Level:

User Auth Type:

Auth Passphrase:

User Data Encrypt Type:

Encrypt Passphrase:

### SNMP Version

Setting	Description	Factory Default
v1, v2c, v3	Specifies the SNMP protocol compatible v1, v2c, & v3 versions.	v1, v2c, v3
v1, v2c-only	Specifies the SNMP protocol compatible v1 & v2c versions.	
v3-only	Specifies the SNMP protocol compatible only v3 version.	
None	Disables the SNMP agent.	

### Read-Only Community

Setting	Description	Factory Default
Max. 32 characters	Specifies the community string to verify read-only access to the SNMP agent. The SNMP agent will use this community string to access all objects with read-only permissions.	public

**Read and Write Community**

Setting	Description	Factory Default
Max. 32 characters	Specifies the community string to verify read and write access to the SNMP agent. The SNMP agent will use this community string to access all objects with read and write permissions.	private

**Admin Auth Level**

Setting	Description	Factory Default
Auth-only	Authentication without encryption.	Auth-only
Both	Authentication with encryption.	
None	No authentication.	

**Admin Auth Type**

Setting	Description	Factory Default
SHA	Authentication is performed by using a SHA privKey.	SHA
MD5	Authentication is performed by using an MD5 privKey.	

**Auth Passphrase**

Setting	Description	Factory Default
8~32 characters	The string is used to authenticate (Admin and Manager).	None

**Admin Data Encrypt Type**

Setting	Description	Factory Default
AES	Encrypts administrator's data with AES algorithm.	AES
DES	Encrypts administrator's data with DES algorithm.	

**Encrypt Passphrase**

Setting	Description	Factory Default
8~32 characters	This string is used to encrypt data (Admin).	None

## SNMP > Trap Setting

This page allows you to enable / disable the SNMP Trap function and configure the settings.

### Trap Setting

**SNMP**

Trap Mode:	<input type="text" value="None"/>
Inform Retry:	<input type="text" value="5"/>
Inform Timeout:	<input type="text" value="1"/>
Trap Destination IP:	<input type="text"/>
Community:	<input type="text"/>

### Trap Mode

Setting	Description	Factory Default
None	Disables SNMP Trap.	None
Trap v1	Send SNMP v1 trap message once.	
Trap v2c	Send SNMP v2c trap message once.	
Inform (v2c)	Retry to send SNMP v2c trap message based on the number of <b>Inform Retry</b> settings.	

### Inform Retry

Setting	Description	Factory Default
1~100	Specifies the number of times the SNMP agent should resend the inform if it does not get the acknowledgment after sending the inform once. This field is valid only when <b>Trap Mode</b> is set to <b>Inform</b> .	5

### Inform Timeout

Setting	Description	Factory Default
1~300 (in second)	Specifies the time that the agent should wait after sending a confirmation request. This field is valid only when <b>Trap Mode</b> is set to <b>Inform</b> .	1

### Trap Destination IP

Setting	Description	Factory Default
IP address	The IP address of the SNMP Server where the trap will be sent.	None

### Community

Setting	Description	Factory Default
Max. 32 characters	The community string used for authentication.	None

# Storm Protection

## Storm Protection > Storm Protection

### Storm Protection

**STORM PROTECTION**

Frame Type	Enable	Rate(fps)
unicast	<input type="checkbox"/>	1024K ▼
multicast	<input type="checkbox"/>	1024K ▼
broadcast	<input checked="" type="checkbox"/>	1024K ▼

### Frame Type

Item	Description	Factory Default
UniCast	Enables or disables UniCast traffic storm control.	Disabled
Multicast	Enables or disables Multicast traffic storm control.	Disabled
Broadcast	Enables or disables Broadcast traffic storm control.	Enabled

### Rate(fps)

Setting	Description	Factory Default
1K~1024K selection menu (per second)	Specifies maximum rate at which packet type is forwarded.	1024K



# Rate Limit

## Rate Limit > Rate Limit

### Rate Limit

---

**RATE LIMIT**

No.	Ingress	Egress
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		

### Rate Limit

Item	Description
No.	Port number of the switch.

### Ingress

Setting	Description	Factory Default
1~10000 (*100k bps)	Ingress Rate Limiting restricts the speed of incoming traffic from a particular device to the switch port.	None

### Egress

Setting	Description	Factory Default
1~10000 (*100k bps)	Egress Rate Limiting restricts the speed of outgoing traffic from witch port to a particular device.	None

## DHCP Server/Relay

Dynamic Host Configuration Protocol (DHCP) is a standardized network protocol. It is used on Internet Protocol (IP) networks for dynamically distributing network configuration parameters. For example, devices can request IP addresses for interfaces from a DHCP server. Using DHCP can also reduce the need for a network administrator or a user to configure these settings manually.

The protocol operates based on the client-server model. When DHCP Clients connect to a network, they will send a broadcast query to request necessary information from a DHCP server. DHCP Servers manage a pool of IP addresses and network configuration information. If they get queries from DHCP Clients, they will automatically distribute IP addresses and network parameters to them.

### DHCP Server/Relay > DHCP Server

This page allows you to enable / disable the DHCP Server function and configure the settings.

### DHCP Server

---

**DHCP SERVER:**

<b>Server Status:</b>	Down
<b>Enable:</b>	<input type="checkbox"/>
<b>Included Start Address:</b>	<input type="text"/>
<b>Included End Address:</b>	<input type="text"/>
<b>Default Gateway:</b>	<input type="text"/>
<b>Name Server:</b>	<input type="text"/>
<b>Lease Time:</b>	<input type="text" value="60"/>

#### Server Status

Status	Description
Down	The DHCP Server is disabled.
Up	The DHCP Server is enabled.

#### Enable

Setting	Description	Factory Default
Unchecked	Disables the DHCP Server feature.	Unchecked
Checked	Enables the DHCP Server feature.	

#### Included Start Address

Setting	Description	Factory Default
IP address	The starting IP address of the pool that DHCP Server managed.	None

#### Included End Address

Setting	Description	Factory Default
IP address	The ending IP address of the pool that DHCP Server managed.	None

**Default Gateway**

Setting	Description	Factory Default
IP address	The default gateway IP address.	None

**Name Server**

Setting	Description	Factory Default
IP address	The DNS server IP address.	None

**Lease Time**

Setting	Description	Factory Default
IP address	Sets the time period for the server to lease an address to a device.	60

## DHCP Server/Relay > DHCP Server Binding

### Binding Table Configuration

---

**DHCP SERVER BINDING**

ID[01-32]	Binding MAC	Binding IP	
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="button" value="Add"/>

### DHCP Server Binding

There are 32 Binding MAC settings available. You can enter ID from 01 to 32 to verify Binding MAC and Binding IP. And you can also add Binding ID by clicking the **Add** button and using the **Delete** button to remove them.

## DHCP Server/Relay > DHCP Relay

DHCP Relay Agents help DHCP Clients forwarding request to DHCP Servers. With DHCP Relay Agents, DHCP Servers and Clients will not know each other. A Relay Agent can connect to more than 1 DHCP Server, so that DHCP Clients will have more resources.

### DHCP Relay

---

**DHCP RELAY**

**Enable:**

**Relay option82:**

**Relay to server1:**

**Relay to server2:**

**Relay to server3:**

**Relay to server4:**

**DHCP RELAY UNTRUST**

No.	Relay Untrust
1	Disable ▼
2	Disable ▼
3	Disable ▼
4	Disable ▼
5	Disable ▼
6	Disable ▼
7	Disable ▼
8	Disable ▼
9	Disable ▼
10	Disable ▼
11	Disable ▼
12	Disable ▼

### Enable

Setting	Description	Factory Default
Unchecked	Disables the DHCP Relay agent.	Unchecked
Checked	Enables the DHCP Relay agent.	

### Relay Option 82

Setting	Description	Factory Default
Unchecked	Disables the DHCP Relay Option 82.	Unchecked
Checked	Enables the DHCP Relay Option 82.	

### Relay to server1

Setting	Description	Factory Default
IP address	The IP address of the first DHCP server that Relay Agent connects to.	None

### Relay to server2

Setting	Description	Factory Default
IP address	The IP address of the second DHCP server that Relay Agent connects to.	None

**Relay to server3**

Setting	Description	Factory Default
IP address	The IP address of the third DHCP server that Relay Agent connects to.	None

**Relay to server4**

Setting	Description	Factory Default
IP address	The IP address of the fourth DHCP server that Relay Agent connects to.	None

**DHCP Relay Untrust**

Terms	Description
No.	Port number of the switch.
Relay Untrust	Per-port <b>Enable</b> or <b>Disable</b> Relay Trust. DHCP frames can pass that port when it is set to <b>Enable</b> only.

## 802.1X

802.1X is an IEEE Standard for Port-based Network Access Control. It provides an authentication mechanism to devices that wish to attach to a LAN or WLAN. This port-based network access control protocol contains 3 parts, supplicant, authenticator, and authentication server. With 802.1X authentication, we can link a user-name with an IP address, MAC address, and port. This provides greater visibility into the network. 802.1X also provides more security because it only allows traffic transmitting on authenticated ports or MAC addresses. The IEEE standard defines it as a Port-based control, to provide more robust service.

### 802.1X > 802.1X

### 802.1X

---

**802.1X**

802.1X Enable:

Server Type: Radius ▼

**802.1X PORT**

No.	Enable Port	Re-Auth	Re-Auth Period(Sec.)
1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
4	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
5	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
6	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
7	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
8	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
9	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
10	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
11	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600
12	<input type="checkbox"/>	<input checked="" type="checkbox"/>	3600

Apply

#### 802.1X Enable

Setting	Description	Factory Default
Unchecked	Disables the 802.1X protocol.	Unchecked
Checked	Enables the 802.1X protocol.	

#### Server Type

Setting	Description	Factory Default
Radius	Use the <b>RADIUS Server</b> settings for authentication.	Radius
Local	Use the <b>Local Database</b> settings for authentication.	

#### Enable Port

Setting	Description	Factory Default
Unchecked	Disables authentication before connecting to a LAN or WAN.	Unchecked
Checked	Enables authentication before connecting to a LAN or WAN.	

**Re-Auth**

Setting	Description	Factory Default
Checked	Enables waiting for a period of time before re-authentication.	Checked
Unchecked	Disables waiting for a period of time before re-authentication.	

**Re-Auth Period (Sec.)**

Setting	Description	Factory Default
60~65535	Specifies a period of time in seconds for re-authentication.	3600



## 802.1X > Local Database

### Local Database

---

**LOCAL DATABASE**

User Name	Password	Confirm Password	
<input style="width: 95%;" type="text"/>	<input style="width: 95%;" type="password"/>	<input style="width: 95%;" type="password"/>	<input type="button" value="Add"/>

### Local Database

Terms	Description
User Name	The user name used to authenticate in 802.1X when server is set to <b>Local</b> .
Password	The password used to authenticate in 802.1X when server is set to <b>Local</b> .
Confirm Password	Type the password again to confirm.

You can add a local database by clicking the **Add** button and using the **Delete** button to remove them.

## 802.1X > RADIUS Server

RADIUS is used in the authentication process. Database of authorized users is maintained on a RADIUS server. There is an authenticator, our switch enabling 802.1X, to forward the authentication requests between authentication (RADIUS) server and client. Allowing or denying the requests decides if the client can connect to a LAN/WAN or not.

### Radius Server

**RADIUS SERVER**

1st Server IP:

1st Server Port:

1st Server Shared Key:

2nd Server IP:

2nd Server Port:

2nd Server Shared Key:

### 1st Server IP

Setting	Description	Factory Default
IP address	The IP address of the first RADIUS server.	None

### 1st Server Port

Setting	Description	Factory Default
Numerical	The UDP port of the first RADIUS Server.	None

### 1st Server Shared Key

Setting	Description	Factory Default
1~32 characters	A key to be shared with the first RADIUS server. It must be the same key of the first RADIUS server.	None

### 2nd Server IP

Setting	Description	Factory Default
IP address	The IP address of the second RADIUS server.	None

### 2nd Server Port

Setting	Description	Factory Default
Numerical	The UDP port of the second RADIUS server.	None

### 2nd Server Shared Key

Setting	Description	Factory Default
1~32 characters	A key to be shared with the second RADIUS server. It must be the same key of the first RADIUS server.	None

# UPnP

Universal Plug and Play (UPnP) is a set of networking protocols that were promoted by the UPnP Forum. UPnP Protocol permits networked devices to discover each other's presence on the network and seamlessly establish functional network services for data sharing, communications, and entertainment.

The concept of UPnP is an extension of plug-and-play – a technology for dynamically attaching devices directly to a computer. But UPnP is not directly related to the earlier plug-and-play technology any more. UPnP devices are plug-and-play in that when connected to a network, they automatically establish working configurations with other devices.

## UPnP > UPnP

### UPnP

---

**UPnP (Interval: 300 - 86400 sec)**

UPnP Enable:

UPnP Interval (sec):

### UPnP Enable

Setting	Description	Factory Default
Unchecked	Disables the UPnP protocol.	Unchecked
Checked	Enables the UPnP protocol.	

### UPnP Interval (sec)

Setting	Description	Factory Default
300~86400	Specifies a timeout interval in seconds.	1800

# Modbus

Modbus is a serial communications protocol that is used with industrial automation equipment such as programmable logic controllers (PLCs), sensors, and meters. It is a common, simple, and robust method of connecting industrial devices.

MODBUS TCP is a variant of the MODBUS family. This vendor-neutral communication protocol is commonly used for the integration of a SCADA system.

According to the standard, Modbus TCP encapsulates the message with an Ethernet TCP/IP wrapper.

## Modbus > Modbus

**Modbus**

---

**MODBUS**

Modbus TCP Enable:

### Modbus TCP Enable

Setting	Description	Factory Default
Unchecked	Disables Modbus TCP.	Unchecked
Checked	Enables Modbus TCP.	

## MODBUS Data Map and Information

The data map addresses for Antaira's switches are shown in the table below.

Address Offset	Data Type	Interpretation	Description
<b>System Information</b>			
0x0000 to 0x0005	1 word	HEX	Port 1 to 6 Status 0x0000 : Link down 0x0001 : Enable 0x0002 : Disable Port 1 to 6 Status Configuration 0x0001 : Enable 0x0002 : Disable

The data map addresses for Antaira's switches are shown in the following table starting from MODBUS for Function Code 4. For example, the address offset 0x0000 (hex) equals MODBUS address 30001, and the address offset 0x0015 (hex) equals MODBUS address 30022. Note that all the information read from Antaira switches are in hex mode. To interpret the information, refer to the ASCII table for the translation (e.g. 0x41 = 'A', 0x6E = 'n').

Address Offset	Data Type	Interpretation	Description
<b>System Information</b>			
0x0000	1 word	HEX	Vendor ID = 0x0000
0x0001	1 word		Unit ID (Ethernet = 1)
0x0002	1 word	HEX	Product Code = 0x0000

0x0010	20 words	ASCII	Vendor Name = "Antaira" Word 0 Hi byte = 'A' Word 0 Lo byte = 'n' Word 1 Hi byte = 't' Word 1 Lo byte = 'a' Word 2 Hi byte = 'i' Word 2 Lo byte = 'r' Word 3 Hi byte = 'a' Word 3 Lo byte = '\0'
0x0030	20 words	ASCII	Product Name = "LMP-0602" Word 0 Hi byte = 'L' Word 0 Lo byte = 'M' Word 1 Hi byte = 'P' Word 1 Lo byte = '-' Word 2 Hi byte = '0' Word 2 Lo byte = '6' Word 3 Hi byte = '0' Word 3 Lo byte = '2' Word 4 Hi byte = '\0' Word 4 Lo byte = '\0'
0x0050	1 word		Product Serial Number
0x0051	2 words	HEX	Firmware Version For example : Word 0 = 0 x 0203 Word 1 = 0 x 0300 Firmware Version was 2.3.3
0x0053	2 words	HEX	Firmware Release Date For example : Word 0 = 0 x 2319 Word 1 = 0 x 1501 Firmware was released on 2015- 01-23 at 19:00
0x0055	3 words	HEX	Ethernet MAC Address Ex : MAC = 7C:CB:0D:AD:DC:14 Word 0 Hi byte = 0 x 7C Word 0 Lo byte = 0 x CB Word 1 Hi byte = 0 x 0D Word 1 Lo byte = 0 x AD Word 2 Hi byte = 0 x DC Word 2 Lo byte = 0 x 14
0x0058	1 word	HEX	Power 1 0x0000 : Off 0x0001 : On
0x0059	1 word	HEX	Power 2 0x0000 : Off 0x0001 : On
0x005A	1 word	HEX	Fault LED Status 0x0000 : Boot error 0x0001 : Normal 0x0002 : Fault
0x0082	1 word	HEX	DO1 0x0001 : Normal 0x0002 : Fault
<b>Port Information</b>			

0x1000 to 0x1005	1 word	HEX	Port 1 to 6 Status 0x0000 : Link down 0x0001 : Link up 0x0002 : Disable 0xFFFF : No port
0x1100 to 0x1105	1 word	HEX	Port 1 to 6 Speed 0x0000 : 10M-Half 0x0001 : 10M-Full 0x0002 : 100M-Half 0x0003 : 100M-Full 0xFFFF : No port
0x1200 to 0x1205	1 word	HEX	Port 1 to 6 Flow Ctrl 0x0000 : Off 0x0001 : On 0xFFFF : No port
0x1300 to 0x1305	1 word	HEX	Port 1 to 6 MDI/MDIX 0x0000: MDI 0x0001: MDIX 0xFFFF: No port
0x1400 to 0x1413 (Port 1) 0x1414 to 0x1427 (Port 2)	20 words	ASCII	Port 1 to 6 Name Port Name = "100FDX,RJ45." Word 0 Hi byte = '1' Word 0 Lo byte = '0' Word 1 Hi byte = '0' Word 1 Lo byte = 'F' ... Word 5 Hi byte = '5' Word 5 Lo byte = '.'
<b>Packets Information</b>			
0x2000 to 0x200B	2 words	HEX	Port 1 to 6 Tx Packets Ex : Port1 Tx Packet Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800

0x2080 to 0x208B	2 words	HEX	Port 1 to 6 Tx Bytes Ex : Port1 Tx Bytes Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
0x2100 to 0x210B	2 words	HEX	Port 1 to 6 Rx Packets Ex : Port1 Rx Packet Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
0x2180 to 0x218B	2 words	HEX	Port 1 to 6 Rx Bytes Ex : Port1 Rx Bytes Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
0x2200 to 0x220B	2 words	HEX	Port 1 to 6 Tx Error Packets Ex : Port1 Tx Error Packet Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
0x2300 to 0x230B	2 words	HEX	Port 1 to 6 Rx Error Packets Ex : Port1 Rx Error Packet Amount = 13244800 Received MODBUS response : 0x13244800 Word 0 = 0 x 1324 Word 1 = 0 x 4800
<b>Redundancy Information</b>			
0x3000	1 word	HEX	Redundancy Protocol 0x0000 : None 0x0001 : RSTP 0x0002 : MSTP 0x0003 : ERPS
0x3100	1 word	HEX	RSTP Root 0xFFFF : None 0x0001 : Root 0x0002 : Not root
0x3200 to 0x3205	1 word	HEX	RSTP Port 1 to 6 Status 0xFFFF : Spanning tree not Enable 0x0000 : Disable 0x0001 : Not spanning tree Port 0x0002 : Link down 0x0003 : Blocked 0x0004 : Learning 0x0005 : Forwarding

0x3300	1 word	HEX	ERPS Port0 Role 0xFFFF : ERPS not enable 0x0000 : Normal 0x0001 : Neighbor 0x0002 : RPL Owner
0x3301	1 word	HEX	ERPS Port1 Role 0xFFFF : ERPS not enable 0x0000 : Normal 0x0001 : Neighbor 0x0002 : RPL Owner
0x3302	1 word	HEX	ERPS Port0 Status 0x0000 : Disable 0x0001 : ERPS not enable 0x0002 : Link down 0x0003 : Forwarding 0x0004 : Learning 0x0005 : Blocking
0x3303	1 word	HEX	ERPS Port1 Status 0x0000 : Disable 0x0001 : ERPS not enable 0x0002 : Link down 0x0003 : Forwarding 0x0004 : Learning 0x0005 : Blocking
0x3304	1 word	HEX	ERPS Port0 Port Ex : ERPS Port0 is Port1 Word 0 = 0 x0001
0x3305	1 word	HEX	ERPS Port1 Port Ex : ERPS Port1 is Port2 Word 0 = 0 x0002



# System Warning

The System Warning function is vital for managing a switch. Users can manage the switch with Syslog, System Event Log, SMTP, and Fault Alarms. By setting up all these system warning features, users will receive warnings when events occur. It increases the flexibility and capability for the user to monitor the remote site network and device statuses.

## System Warning > Syslog Setting

### Syslog Setting

---

**SYSLOG**

Syslog Mode:

Syslog Server IP Address:

### Syslog Mode

Setting	Description	Factory Default
Disable	Disables Syslog event notifications.	Disable
Local Only	Transmits event notification messages to the local system.	
Remote Only	Transmits event notification messages to the remote Syslog server.	
Local and Remote	Transmits event notification messages to both of the local system and the remote Syslog server.	


### Syslog Server IP Address

Setting	Description	Factory Default
IP address	The IP address of the Syslog server.	None

## System Warning > System Event Log

The system list window displays up to 5 pages of system event log information.

You can click the **Refresh** button to update system event log information.



## System Warning > SMTP Setting

The Simple Mail Transfer Protocol (SMTP) is for e-mail transmission.

### SMTP Setting

---

**SMTP**

**Email Alert:** Disable ▼

**SMTP Server Address:**

**Sender E-mail Address:**

**Mail Subject:**

**Authentication:**

**Username:**

**Password:**

**Recipient E-mail Address 1:**

**Recipient E-mail Address 2:**

**Recipient E-mail Address 3:**

**Recipient E-mail Address 4:**

Apply

### Email Alert

Setting	Description	Factory Default
Disable	Disables transmission system warning events by e-mail.	Disable
Enable	Enables transmission system warning events by e-mail.	

### SMTP Server Address

Setting	Description	Factory Default
IP address	The IP address of the SMTP server.	None

### Sender E-mail Address

Setting	Description	Factory Default
E-mail address	The recipients will see in the From field of the Email alert.	None

### Mail Subject

Setting	Description	Factory Default
Max. 320 characters	The subject of the Email alert.	None

### Authentication

Setting	Description	Factory Default
Unchecked	Send Email alerts without SMTP authentication.	Unchecked
Checked	Send Email alerts with SMTP authentication.	

**Username**

Setting	Description	Factory Default
Max. 320 characters	The authentication username.	None

**Password**

Setting	Description	Factory Default
Max. 320 characters	The authentication password.	None

**Recipient E-mail Address 1~4**

Setting	Description	Factory Default
E-mail address	You can set up to 4 recipient e-mail addresses to receive any system warning message.	None

## System Warning > Event Selection

This page allows you to select an event type, such as System Cold Start, Link Up, Link Down, Link Up and Down Link, and to send a system warning message to SYSLOG or SMTP. Cold start indicates that the unit had been rebooted.

### Event Selection

---

**EVENT SELECTION**

Event	SYSLOG	SMTP
System Cold Start:	<input type="checkbox"/>	<input type="checkbox"/>

**EVENT SELECTION PORT**

Port No.	SYSLOG	SMTP
1	Disable ▼	Disable ▼
2	Disable ▼	Disable ▼
3	Disable ▼	Disable ▼
4	Disable ▼	Disable ▼
5	Disable ▼	Disable ▼
6	Disable ▼	Disable ▼
7	Disable ▼	Disable ▼
8	Disable ▼	Disable ▼
9	Disable ▼	Disable ▼
10	Disable ▼	Disable ▼
11	Disable ▼	Disable ▼
12	Disable ▼	Disable ▼

### System Cold Start - Syslog

Setting	Description	Factory Default
Unchecked	Disables recording system cold start events to Syslog.	Unchecked
Checked	Enables recording system cold start events to Syslog.	

### System Cold Start - SMTP

Setting	Description	Factory Default
Unchecked	Disables recording system cold start events to SMTP.	Unchecked
Checked	Enables recording system cold start events to SMTP.	

### Port - Syslog

Setting	Description	Factory Default
Disable	Disables recording port Link Up/ Link Down events to Syslog.	Disable
Enable	Enables recording port Link Up/ Link Down event to Syslog.	

### Port - SMTP

Setting	Description	Factory Default
Disable	Disables recording port Link Up/ Link Down events to SMTP.	Disable
Enable	Enables recording port Link Up/ Link Down event to SMTP.	

## System Warning > Fault Alarm

This page allows you to select the fault alarms you would like to receive.

### Fault Alarm

---

**FAULT ALARM**

Power1 Failure:

Power2 Failure:

Port No.	Link Down/Broken
1	<input type="checkbox"/>
2	<input type="checkbox"/>
3	<input type="checkbox"/>
4	<input type="checkbox"/>
5	<input type="checkbox"/>
6	<input type="checkbox"/>
7	<input type="checkbox"/>
8	<input type="checkbox"/>
9	<input type="checkbox"/>
10	<input type="checkbox"/>
11	<input type="checkbox"/>
12	<input type="checkbox"/>

### Power1 Failure

Setting	Description	Factory Default
Unchecked	Disables Power1 Failure LED indicator on the device's front panel.	Unchecked
Checked	Enables Power1 Failure LED indicator on the device's front panel.	

### Power2 Failure

Setting	Description	Factory Default
Unchecked	Disables Power2 Failure LED indicator on the device's front panel.	Unchecked
Checked	Enables Power2 Failure LED indicator on the device's front panel.	

### Link Down/ Broken

Setting	Description	Factory Default
Unchecked	Disables Link Down/ Broken LED indicator on the LAN port jack.	Unchecked
Checked	Enables Link Down/ Broken LED indicator on the LAN port jack.	

# MAC Table

## MAC Table > MAC Address Table

The MAC address table is the filtering database that supports queries by the forwarding process, as to whether a frame received by a given port with a given destination MAC address is to be forwarded through a given potential transmission port.

<b>MAC Address Table</b>			
<b>MAC ADDRESS TABLE</b>			
<b>VID</b>	<b>MAC</b>	<b>Type</b>	<b>Port</b>
1	01:00:5e:7f:ff:fa	static	10

### MAC Address Table

Terms	Description
VID	The ID of VLAN.
MAC	The MAC address.
Type	The type of this MAC address.
Port	The port on the switch to which the MAC address belongs.

## MAC Table > MAC Table Configuration

This page allows you to configure the MAC Table.

### MAC Table Configuration

---

**ADD MAC ADDRESS**

VID	MAC	01	02	03	04	05	06	07	08	09	10	11	12	
		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="button" value="Add"/>

**MAC TABLE CONFIGURATION**

VID	MAC	01	02	03	04	05	06	07	08	09	10	11	12	
1	01:00:5e:7f:ff:fa	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="button" value="Delete"/>

**Add MAC Address**

Terms	Description
VID	Specifies the ID of VLAN.
MAC	Specifies the MAC address.
01~12 (numbers depend on the device)	Specifies list of ports on the switch.



# Maintenance

In the Maintenance menu, you can upgrade the firmware, reboot, and restore the default value.

## Maintenance > Upgrade

### Upgrade

---

Please do not power off or unplug your machine during upgrading

#### FIRMWARE UPGRADE

Image:	<input type="button" value="Choose File"/> No file chosen	<input type="button" value="Upgrade"/>
--------	---	--

### Upgrading the firmware

To upgrade firmware on the device, follow the below steps:

1. Download the firmware file from Antaira's website and store to your PC.
2. Log into the Admin user on the device.
3. Go to **Maintenance > Upgrade** page.
4. Click **Choose File** button to select the file you have downloaded.
5. Click **Upload** button. It may take a few minutes. Do not turn off the device.

## Maintenance > Reboot

### Reboot Device

---

Reboots the operating system of your device

Warning: There are unsaved changes that will be lost while rebooting!

You can reboot the device by clicking the **Apply** button on **Maintenance > Reboot** page.

## Maintenance > Default

### Reset Factory Default

---


Reset factory default of your device

You can reset the switch to Factory Default values by clicking the **Apply** button on **Maintenance > Default** page.

# Configuration


In the Configuration menu, you can save, backup, and restore settings.

## Configuration > Save



You can click the **Save** button on **Configuration > Save** page once all the settings had been configured.

## Configuration > Backup & Restore



### Configuration Management


Feature	Description
Backup Configuration	Stores the configuration backup file.
Upload Configuration	Restore the configuration backup from the backup file.

### User Management

Feature	Description
Save Running Config to USB	Stores the running-config file to the USB drive.
Save Startup Config to USB	Stores the startup-config file to the USB drive.
Upload Config from USB	Restore the startup-config file from the USB drive.

## Log out

You can logout of the web management by clicking **Log out** from the menu.



**Log out**

# Command Line Management

You can configure the switch using command line.

## Configuration by serial console

1. Connect your PC to the switches' console port.
2. Launch the serial terminal program.
3. Configure the port settings of the serial terminal program to match the console port:
  - 115200 baud
  - 8 data bits
  - No parity
  - 1 stop bit
  - No flow control
4. The administrator username is admin and the password is admin by default. Enter the username and password to login the serial console.

```
User Access Verification

Username: admin
Password:

SWES> en

SWES# configure terminal
```

## Configuration by Telnet console

1. Connect your PC and the switches on the same logical subnetwork.
2. Launch the Telnet program.
3. Configure the switches default settings of the Telnet program:
  - IP Address: 192.168.1.254
  - Subnet Mask: 255.255.255.0
  - Default Gateway: none
4. The administrator username is admin and the password is admin by default. Enter the username and password to login the Telnet console.

```
User Access Verification

Username: admin
Password:

SWES> en

SWES# configure terminal
```

## Commander Groups

### System Group

Command	Mode
hostname [ Switch ]	configure
no hostname	configure
system location [ none ]	configure
system contact [ none ]	configure
no system location	configure
no system contact	configure
show system uptime	configure
show system mac	configure
show system version firmware	configure
show system version loader	configure
Username [ admin   manager   user ] password [ PASSWORD ]	configure

### IP Group

Command	Mode
boot host dhcp	configure
ip address [ ip_addr ] [ ip_mask ]	configure
ip default-gateway [ ip_router ]	configure
ip name-server [ ip_addr_string ]	configure
no boot host dhcp	configure
no ip default-gateway	configure
no ip name-server	configure
show boot host dhcp	configure
show ip address	configure
show ip default-gateway	configure
show ip name-server	configure
show ip mode	configure

### Time Group

Command	Mode
ntp time update	configure
ntp client timeserver [ ip_addr_string ]	configure
clock time [ hh:mm:ss ] [ day ] [ month ] [ year ]	configure
clock time zone [ area ] [ city ]	configure
ntp client sync [ minute   hour   day   month   year ] [ NUMBER ]	configure
no ntp client timeserver	configure
no clock time zone	configure
no ntp client sync [ minute   hour   day   month   year ] [ NUMBER ]	configure
show ntp client timeserver	configure
show clock time zone	configure
show ntp client sync [ minute   hour   day   month   year ] [ NUMBER ]	configure

**Port Group**

Command	Mode
speed duplex [ 10   100   1000 ] [ full   half ]	interface
flowcontrol [ on   off ]	interface
name [ string ]	interface
shutdown	interface
no speed duplex	interface
no flowcontrol	interface
no name	interface
no shutdown	interface
show speed duplex	interface
show flowcontrol	interface
show name	interface
show link rx	interface
show link tx	interface
show link summary	interface
rate-limit [ egress   ingress ] [ RATE VALUE ]	interface
no rate-limit egress	interface
no rate-limit ingress	interface
show link status	interface
show interface transceiver	configure

**VLAN Group**

Command	Mode
management vlan [ vlan_id ]	configure
name [ vlan_name ]	vlan
member [ member_portlist ] [ <untag_portlist> ]	vlan
switchport pvid [ vlan_id ]	interface
switchport filter [ tagged   untagged ]	interface
no name	vlan
no member	vlan
no switchport pvid	interface
no switchport filter	interface
show name	vlan
show member	vlan
show switchport pvid	interface
show switchport filter	interface
switchport mode [ d(dot1q-tunnel)   c(customer)   p(provider) ]	interface

**ERPS Group**

Command	Mode
ethernet ring erps major	configure
enable	erps
disable	erps
rpl [ port0   port1 ] [ owner   neighbor ]	erps
aps-channel [ channel ID ]	erps
revertive	erps

Command	Mode
clear	erps
port0 interface [ interface name ]	erps
port1 interface [ interface name ]	erps
fs [ port0   port1 ]	erps
ms [ port0   port1 ]	erps
ring-id [ erps ring ID ]	erps
timer hold-off [ 0~1000 ]	erps
timer guard [ 10~2000 ]	erps
timer wtr [ 1~12 ]	erps
no rpl [ port0   port1 ]	erps
no aps-channel	erps
no revertive	erps
no port0	erps
no port1	erps
no ring-id	erps
no timer hold-off	erps
no timer guard	erps
no timer wtr	erps
show status	erps
show brief	erps
show port status	erps
show configuration	erps
mel [ 0~7 ]	erps
no fs	erps
no ms	erps

### PoE Group

Command	Mode
power inline never	interface
keepalive ip [ IP_Address ]	interface
keepalive time [ seconds ]	interface
schedule [ monday~sunday ] enable	interface
schedule [ monday~sunday ] starttime [ Hour ]	interface
schedule [ monday~sunday ] endtime [ Hour ]	interface
no power inline never	interface
no keepalive ip	interface
no keepalive time	interface
no schedule [ monday~sunday ] enable	interface
no schedule [ monday~sunday ] starttime	interface
no schedule [ monday~sunday ] endtime	interface
show power inline status	interface
show keepalive ip	interface
show keepalive time	interface
show schedule [ monday~sunday ] enable	interface
show schedule [ monday~sunday ] starttime	interface

Command	Mode
show schedule [ monday~sunday ] endtime	interface

### STP Group

Command	Mode
spanning-tree mode [ rstp   mst ]	configure
spanning-tree priority [ priority value ]	configure
spanning-tree forward-time [ forward time ]	configure
spanning-tree hello-time [ hello time ]	configure
spanning-tree max-age [ max_age ]	configure
spanning-tree cost [ link_cost_value ]	interface
spanning-tree port-priority [ port priority ]	interface
spanning-tree link-type [ point-to-point   point-to-multiple ]	interface
spanning-tree auto-edge off	interface
spanning-tree admin-edge on	interface
spanning-tree stp disable	interface
no spanning-tree mode	configure
no spanning-tree priority	configure
no spanning-tree forward-time	configure
no spanning-tree hello-time	configure
no spanning-tree max-age	configure
no spanning-tree mst [ instance_ID ] priority	configure
no spanning-tree cost	interface
no spanning-tree port-priority	interface
no spanning-tree link-type	interface
no spanning-tree auto-edge	interface
no spanning-tree admin-edge	interface
no spanning-tree stp	interface
show spanning-tree mode	configure
show spanning-tree priority	configure
show spanning-tree forward-time	configure
show spanning-tree hello-time	configure
show spanning-tree max-age	configure
show spanning-tree cost	interface
show spanning-tree port-priority	interface
show spanning-tree link-type	interface
show spanning-tree auto-edge	interface
show spanning-tree admin-edge	interface
show spanning-tree stp	interface
spanning-tree mst [ instance_ID ] priority [ priority ]	configure
spanning-tree mst name [ NAME ]	configure
spanning-tree mst revision [ REVISION ]	configure
spanning-tree mst instance [ instance_ID ] vlan [ vlan_grp ]	configure
spanning-tree mst [ instance_ID ] cost [ cost_value ]	interface
spanning-tree mst [ instance_ID ] port-priority [ priority ]	interface
no spanning-tree mst name	configure



Command	Mode
no spanning-tree mst revision	configure
no spanning-tree mst instance [ instance_ID ] vlan	configure
no spanning-tree mst [ instance_ID ] cost	interface
no spanning-tree mst [ instance_ID ] port-priority	interface
show spanning-tree mst name	configure
show spanning-tree mst revision	configure
show spanning-tree mst instance [ instance_ID ] vlan	configure
show spanning-tree mst [ instance_ID ] priority	configure
show spanning-tree mst [ instance_ID ] cost	interface
show spanning-tree mst [ instance_ID ] port-priority	interface

### Event Group

Command	Mode
event smtp power1 enable	configure
event smtp power2 enable	configure
event smtp cold-start enable	configure
event smtp warm-start enable	configure
event smtp authentication-failure enable	configure
event smtp erps-change enable	configure
event smtp interface [ INTERFACE_NAME ] up	configure
event smtp interface [ INTERFACE_NAME ] down	configure
no event smtp power1	configure
no event smtp power2	configure
no event smtp cold-start	configure
no event smtp warm-start	configure
no event smtp authentication-failure	configure
no event smtp erps-change	configure
no event smtp interface [ INTERFACE_NAME ] up	configure
no event smtp interface [ INTERFACE_NAME ] down	configure
show event smtp power1	configure
show event smtp power2	configure
show event smtp cold-start	configure
show event smtp warm-start	configure
show event smtp authentication-failure	configure
show event smtp erps-change	configure
show event smtp interface [ INTERFACE_NAME ] up	configure
show event smtp interface [ INTERFACE_NAME ] down	configure
event syslog power1 enable	configure
event syslog power2 enable	configure
event syslog cold-start enable	configure
event syslog warm-start enable	configure
event syslog authentication-failure enable	configure
event syslog erps-change enable	configure
event syslog interface [ INTERFACE_NAME ] up	configure
event syslog interface [ INTERFACE_NAME ] down	configure

Command	Mode
no event syslog power1	configure
no event syslog power2	configure
no event syslog cold-start	configure
no event syslog warm-start	configure
no event syslog authentication-failure	configure
no event syslog erps-change	configure
no event syslog interface [ INTERFACE_NAME ] up	configure
no event syslog interface [ INTERFACE_NAME ] down	configure
show event syslog power1	configure
show event syslog power2	configure
show event syslog cold-start	configure
show event syslog warm-start	configure
show event syslog authentication-failure	configure
show event syslog erps-change	configure
show event syslog interface [ INTERFACE_NAME ] up	configure
show event syslog interface [ INTERFACE_NAME ] down	configure
event alarm power1 enable	configure
event alarm power2 enable	configure
event alarm interface [ INTERFACE_NAME ] down	configure
no event alarm power1	configure
no event alarm power2	configure
no event alarm interface [ INTERFACE_NAME ] down	configure
show event alarm power1	configure
show event alarm power2	configure
show event alarm interface [ INTERFACE_NAME ] down	configure
event apply	configure

### Syslog Group

Command	Mode
syslog server [ IP_address ]	configure
syslog mode [ all   local   remote ]	configure
no syslog server	configure
no syslog mode	configure
show syslog server	configure
show syslog mode	configure
show syslog log	configure
syslog apply	configure

### SMTP Group

Command	Mode
smtp enable	configure
smtp sender [ E-MAIL_ADDR ]	configure
smtp subject [ subject_text ]	configure
smtp server address [ GMAIL_SMPT_SERVER ]	configure
smtp server port [ GMAIL_SMPT_SERVER ]	configure
smtp authentication enable	configure

Command	Mode
smtp authentication username [ GMAIL_ACCOUNT ]	configure
smtp authentication password [ GMAIL_PASS ]	configure
smtp receive [ 1   2   3   4 ] [ e-mail_address ]	configure
no smtp enable	configure
no smtp sender	configure
no smtp subject	configure
no smtp server address	configure
no smtp server port	configure
no smtp authentication enable	configure
no smtp authentication username	configure
no smtp authentication password	configure
no smtp receive [ 1   2   3   4 ]	configure
show smtp state	configure
show smtp sender	configure
show smtp subject	configure
show smtp server address	configure
show smtp server port	configure
show smtp authentication enable	configure
show smtp authentication username	configure
show smtp receive [ 1   2   3   4 ]	configure

### SNMP Group

Command	Mode
snmp server enable [ <v1-v2c-only   v3-only> ]	configure
snmp server community [ ro   rw ] [ community_name ]	configure
snmp server v3 level [ admin   user ] [ auth   noauth   priv ]	configure
snmp server v3 auth [ admin   user ] [ md5   sha ] [ PWD ]	configure
snmp server v3 encryption [ admin   user ] [ des   aes ] [ PWD ]	configure
no snmp server enable	configure
no snmp server community [ ro   rw ]	configure
no snmp server v3 level [ admin   user ]	configure
no snmp server v3 auth [ admin   user ]	configure
no snmp server v3 encryption [ admin   user ]	configure
show snmp server enable	configure
show snmp server community [ ro   rw ]	configure
show snmp server v3 level [ admin   user ]	configure
show snmp server v3 auth [ admin   user ]	configure
show snmp server v3 encryption [ admin   user ]	configure
snmp trap enable	configure
snmp trap host [ DESTINATION_IP ]	configure
snmp trap version [ 1   2c   3 ] [ traps   inform ]	configure
snmp trap community [ trap_community_name ]	configure
snmp trap inform retry [ retry_time ]	configure
snmp trap inform timeout [ retry_interval ]	configure
snmp trap v3 user [ user_ID ]	configure

Command	Mode
snmp trap v3 level [ auth   noauth   priv ]	configure
snmp trap v3 engine-ID [ engineID ]	configure
snmp trap v3 auth [ md5   sha ] [ PASSWORD ]	configure
snmp trap v3 encryption [ des   aes ] [ PASSWORD ]	configure
no snmp trap enable	configure
no snmp trap host	configure
no snmp trap version	configure
no snmp trap community	configure
no snmp trap inform retry	configure
no snmp trap inform timeout	configure
no snmp trap v3 user	configure
no snmp trap v3 level	configure
no snmp trap v3 engine-ID	configure
no snmp trap v3 auth	configure
no snmp trap v3 encryption	configure
show snmp trap enable	configure
show snmp trap host	configure
show snmp trap version	configure
show snmp trap community	configure
show snmp trap inform retry	configure
show snmp trap inform timeout	configure
show snmp trap v3 user	configure
show snmp trap v3 level	configure
show snmp trap v3 engine-ID	configure
show snmp trap v3 auth	configure
show snmp trap v3 encryption	configure

### File Group

Command	Mode
copy running-config startup-config	configure
copy startup-config running-config	configure
copy usb startup-config	configure

### Port Mirror Group

Command	Mode
monitor enable	configure
monitor source [ rx   tx   both ] [ port_list ]	configure
monitor destination [ dest_port_number ]	configure
no monitor enable	configure
no monitor source	configure
no monitor destination	configure
show monitor enable	configure
show monitor source	configure
show monitor destination	configure

**QoS Group**

Command	Mode
qos queue-schedule [ strict   wrr ]	configure
qos map cos [ priority type ] to tx-queue [ queue ]	configure
qos map dscp [ [ priority type ] to tx-queue [ [ queue ]	configure
qos trust [ cos   dscp ]	interface
qos default cos [ cos_default_value ]	interface
no qos queue-schedule	configure
no qos map cos [ priority type ]	configure
no qos map dscp [ priority type ]	configure
no qos trust	interface
no qos default cos	interface
show qos queue-schedule	configure
show qos map cos [ priority type ]	configure
show qos map dscp [ priority type ]	configure
show qos trust	interface
show qos default cos	interface

**IGMP Group**

Command	Mode
igmp snooping enable	configure
igmp snooping query max-respond-time [ 1..12 ]	configure
igmp snooping query interval [ 1..3600 ]	configure
igmp snooping last-member count [ 2..10 ]	configure
igmp snooping last-member interval [ 60..300 ]	configure
igmp snooping querier enable	configure
igmp snooping fast-leave enable	interface
no igmp snooping enable	configure
no igmp snooping query max-respond-time	configure
no igmp snooping query interval	configure
no igmp snooping last-member count	configure
no igmp snooping last-member interval	configure
no igmp snooping querier	configure
no igmp snooping fast-leave	interface
show igmp snooping mdb	configure
show igmp snooping all	configure
show igmp snooping fast-leave	interface

**Trunk Group**

Command	Mode
trunk group [ group ] [ static   lacp ] [ interface_list ]	configure
show trunk group	configure
show trunk group [ 1-8 ]	configure

**DHCP Server/Relay Group**

Command	Mode
dhcp service server	configure

Command	Mode
dhcp server included-address [ IP_START ] [ IP_END ]	configure
dhcp server default-gateway [ router_ip ]	configure
dhcp server name-server [ dns_ip ]	configure
dhcp server lease [ dhcp_lease_time ]	configure
dhcp server binding [ bind_num ] [ MAC ] [ bind_IP ]	configure
dhcp service relay	configure
dhcp relay server [ server_number ] [ IP ]	configure
dhcp relay information option	configure
dhcp relay untrust	interface
no dhcp service server	configure
no dhcp server included-address	configure
no dhcp server default-gateway	configure
no dhcp server name-server	configure
no dhcp server lease	configure
no dhcp server binding [ bind_num ]	configure
no dhcp service relay	configure
no dhcp relay server [ server_number ]	configure
no dhcp relay information option	configure
no dhcp relay untrust	configure
show dhcp service	interface
show dhcp server status	configure
show dhcp server included-address	configure
show dhcp server default-gateway	configure
show dhcp server name-server	configure
show dhcp server lease	configure
show dhcp server binding [ bind_num ] [ MAC ] [ bind_IP ]	configure
show dhcp relay enable	configure
show dhcp relay server [ server_number ]	configure
show dhcp relay information option	configure
show dhcp relay untrust	interface

### UPnP Group

Command	Mode
upnp enable	configure
upnp advertisement interval [ SEC ]	configure
no upnp enable	configure
no upnp advertisement interval	configure
show upnp enable	configure
show upnp advertisement interval	configure

### Modbus Group

Command	Mode
modbus tcp server	configure
no modbus tcp server	configure
show modbus tcp server	configure

### 802.1X Group

Command	Mode
dot1x enable	configure
dot1x authentication server type [ local   radius ]	configure
dot1x authentication server 1 ip [ IP ]	configure
dot1x authentication server 1 port [ PORT ]	configure
dot1x authentication server 1 share-key [ KEY ]	configure
dot1x authentication server 2 ip [ IP ]	configure
dot1x authentication server 2 port [ PORT ]	configure
dot1x authentication server 2 share-key [ KEY ]	configure
dot1x local-db [ USER ] [ PASSWORD ]	configure
dot1x authenticator enable	interface
dot1x reauthentication enable	interface
dot1x reauthentication period [ SEC ]	interface
no dot1x enable	configure
no dot1x authentication server type	configure
no dot1x authentication server 1 ip	configure
no dot1x authentication server 1 port	configure
no dot1x authentication server 1 share-key	configure
no dot1x authentication server 2 ip	configure
no dot1x authentication server 2 port	configure
no dot1x authentication server 2 share-key	configure
no dot1x local-db [ USER ] [ PASSWORD ]	configure
no dot1x authenticator enable	interface
no dot1x reauthentication enable	interface
no dot1x reauthentication period	interface
show dot1x enable	configure
show dot1x authentication server type	configure
show dot1x authentication server 1 ip	configure
show dot1x authentication server 1 port	configure
show dot1x authentication server 1 share-key	configure
show dot1x authentication server 2 ip	configure
show dot1x authentication server 2 port	configure
show dot1x authentication server 2 share-key	configure
show dot1x local-db [ USER ] [ PASSWORD ]	configure
show dot1x brief	configure
show dot1x server brief	configure
show dot1x brief	interface
show dot1x server brief	interface
show dot1x authenticator enable	interface
show dot1x reauthentication enable	interface
show dot1x reauthentication period	interface

### IPv6 Group

Command	Mode
ipv6 enable	configure
ipv6 address add [ IPV6_ADDR</PREFIX_LEN> ]	configure

Command	Mode
ipv6 neighbor flush	configure
ipv6 ping [ IPV6_ADDR ] [ <size PKG_SIZ>   <repeat PKG_CNT> ]	configure
no ipv6 enable	configure
no ipv6 address [ IPV6_ADDR/PREFIX_LEN ]	configure
show ipv6 enable	configure
show ipv6 address	configure
show ipv6 neighbor	configure

### TFTP Group

Command	Mode
tftp upgrade	configure
tftp server ip [ IP_ADDRESS ]	configure
tftp file name [ UPGRADE_FILE_NAME ]	configure

### MAC Table Group

Command	Mode
mac set [ 1-4094 ] [ MAC ] [ PORT ]	configure
no mac set [ 1-4094 ] [ MAC ]	configure
show mac set	configure
clear mac address-table dynamic	configure

### LLDP Group

Command	Mode
lldp enable	configure
lldp timer [ 5-32767 ] (s)	configure
no lldp	configure
no lldp timer	configure
show lldp	configure
show lldp neighbor	configure
show lldp timer	configure

### Storm Protection Group

Command	Mode
storm protection [ broadcast   multicase   unicast ] enable	configure
storm protection [ broadcast   multicase   unicast ] rate [ RATE_VALUE ]	configure
no storm protection [ broadcast   multicase   unicast ]	configure
no storm protection [ broadcast   multicase   unicast ] rate	configure
show storm protection [ broadcast   multicase   unicast ]	configure
show storm protection [ broadcast   multicase   unicast ] rate	configure

### Security Group

Command	Mode
Security [ http   https   ssh   telnet   usb ] enable	configure
Security show [ http   https   ssh   telnet   usb ]	configure
Security no [ http   https   ssh   telnet   usb ]	configure



## Save and Load Configuration File to/from USB

1. CLI: enable > configure terminal > copy running-config usb (path)

```
User Access Verification

Username: Admin
Password:

SWES> en

SWES# configure terminal

SWES<config># copy
running-config startup-config usb
SWES<config># copy running-config
startup-config usb

SWES<config># copy running-config usb file1

SWES<config># copy running-config usb /test/file2
```

Fill in the folder and filename behind the copy **running-config usb** command.

Ex: file1, / folder /file2.

2. CLI: enable > configure terminal > copy startup-config usb (path)

```
User Access Verification

Username: Admin
Password:

SWES> en

SWES# configure terminal

SWES<config># copy
running-config startup-config usb
SWES<config># copy startup-config
runing-config usb

SWES<config># copy startup-config usb file1

SWES<config># copy startup-config usb /test/file2
```

Fill in the folder and filename behind the copy **startup-config usb** command.

Ex: file1, / folder /file2.

3. CLI: enable > configure terminal > copy usb startup-config (path)

```
User Access Verification

Username: Admin
Password:

SWES> en

SWES# configure terminal

SWES<config># copy
running-config startup-config usb
SWES<config># copy usb
startup-config firmware

SWES<config># copy usb
startup-config destination file
firmware destination file

SWES<config># copy usb startup-config file1
```

Fill in the folder and filename behind the **copy usb startup-config** command.

Ex: file1, / folder /file2.

## Upgrade via TFTP

CLI: enable > configure terminal > tftp server ip [IP\_ADDRESS] > tftp file name [UPGRADE\_FILE\_NAME]  
> tftp upgrade

```
Switch> enable

Switch# configure terminal

Switch(config)# tftp server ip 192.168.1.237

Switch(config)# tftp file name 240.dat

Switch(config)# tftp upgrade
```

Fill in the TFTP server IP and upgrade file name behind the **tftp server ip [IP\_ADDRESS]** and **tftp file name [UPGRADE\_FILE\_NAME]**